

# SEALEY

## INFRARED QUARTZ HEATER - WALL/TRIPOD MOUNTING 1.2KW/230V

MODEL NO: IR12, IR12CT

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to  
Instruction  
Manual



Hot surfaces



Warning!  
electricity



Do not cover



Indoor use only

### 1. SAFETY

#### 1.1. ELECTRICAL SAFETY

- ❑ **WARNING!** It is the user's responsibility to check the following:  
Check all electrical equipment and appliances to ensure that they are safe before using. Inspect power supply leads, plugs and all electrical connections for wear and damage. Sealey recommend that an RCD (Residual Current Device) is used with all electrical products.

If the product is used in the course of business duties, it must be maintained in a safe condition and routinely PAT (Portable Appliance Test) tested.

Electrical safety information, it is important that the following information is read and understood.

Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.

Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that they are secure.

**Important:** Ensure that the voltage rating on the appliance suits the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating in these instructions.

- ✗ **DO NOT** pull or carry the appliance by the power cable.
- ✗ **DO NOT** pull the plug from the socket by the cable.
- ✗ **DO NOT** use worn or damaged cables, plugs or connectors. Ensure that any faulty item is repaired or is replaced immediately by a qualified electrician.

This product is fitted with a BS1363/A 3 pin plug.

If the cable or plug is damaged during use, switch off the electricity supply and remove from use.

Ensure that repairs are carried out by a qualified electrician.

Replace a damaged plug with a BS1363/A 3 pin plug. If in doubt contact a qualified electrician.

a) Connect the GREEN/YELLOW earth wire to the earth terminal 'E'.

b) Connect the BROWN live wire to the live terminal 'L'.

c) Connect the BLUE neutral wire to the neutral terminal 'N'.


Ensure that the cable outer sheath extends inside the cable restraint and that the restraint is tight.

Sealey recommend that repairs are carried out by a qualified electrician.

#### 1.2. GENERAL SAFETY

**CAUTION - Some parts of this product can become very hot and cause burns. Particular attention has to be given to where children and vulnerable children are present.**

- ❑ **WARNING!** To reduce the risk of fire, keep textiles, curtains or any other flammable material a minimum distance of 2m from the air outlet.
- ❑ **WARNING!** Disconnect the heater from the mains power supply before carrying out any servicing or maintenance.
- ✓ Maintain the heater in good order and clean condition for best and safest performance. Replace or repair damaged parts.
- ✓ Locate heater in a suitable work area and keep area clean, tidy and free from unrelated materials. Ensure there is adequate lighting and keep the immediate area in front of the outlet grille clear.
- ✓ Allow the unit to cool before storage. When not in use, disconnect from the mains power supply and store in a safe, cool, dry, childproof area.
- ✓ Use this heater on a horizontal and stable surface.
- ✗ **DO NOT** use the heater where there are flammable liquids, solids or gases such as petrol, solvents, aerosols etc, or where heat sensitive materials may be stored.
- ✗ **DO NOT** place the heater near items that may be damaged by heat, allow at least 2m clearance in front of the heater.
- ✗ **DO NOT** allow the heater to get wet as this may cause an electric shock, causing damage to the heater and possible personal injury.
- ✗ **DO NOT** use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.
- ✗ **DO NOT** let power lead hang over an edge (i.e. table), or touch a hot surface, lie in the beam of heat, or run under a carpet.
- ✗ **DO NOT** use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
- ✗ **DO NOT** operate the heater when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- ✗ **DO NOT** insert or allow objects to enter any openings of heater as this may cause an electric shock, fire or damage to heater.
- ✗ **DO NOT** use heater if the power cord, plug or the heater is damaged, or if the heater has become wet.
- ✗ **DO NOT** use the heater for any purpose other than for which it is designed.



- × **DO NOT** use the heater with a programmer, timer or any other device that switches the heater on automatically.
  - × **DO NOT** touch the lamps, even when cold.
  - × **DO NOT** allow children to touch or to operate the heater.
  - × **DO NOT** locate the heater below an electrical socket outlet.
  - × **DO NOT** use the heater without the grille fitted.
  - × **DO NOT** use the heater out of doors. These heaters are designed for indoor use only.
  - × **DO NOT** use this heater if it has been dropped.
  - × **DO NOT** use if there are visible signs of damage to the heater.
  - × **DO NOT** cover heater when in use, and do not obstruct the air inlet and outlet grilles.
  - × **DO NOT** place heater too close to yourself or any object, allow the air to circulate freely.
  - × **DO NOT** touch the outlet grille of the heater during and immediately after use as it will be hot.
  - WARNING:** The fireguard of this heater is intended to prevent direct access to heating elements and must be in place when the heater is in use.
  - WARNING:** The fireguard does not give full protection for young children and for infirm persons.
  - ✓ Children of less than 3 years should be kept away unless continuously supervised.
  - ✓ Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years to less than 8 shall not plug in, regulate and clean the appliance or perform user maintenance.
- This appliance can be used by children aged from 8 years and above and persons with physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

## 2. INTRODUCTION

Electric heater with infrared quartz lamp. Suitable for wall or overhead mounting. Reaches maximum heat output within seconds of being turned on. Supplied with 1.8m power cable and mounting bracket. A totally dry heat with no condensation, no gas, no fumes and no smell.

## 3. SPECIFICATION

Model No: ..... IR12 / IR12CT  
 Fuse Rating: ..... 13A  
 Minimum Mounting Height: ..... 1.8m  
 Mounting Bracket Stand-Off: ..... 134mm  
 Overall Dimensions IR12 (W x D x H) ..... 412 x 95 x 210mm  
 Overall Dimensions IR12CT (W x D x H) 1100 x 1100 x 1490mm  
 Plug Type: ..... 3-Pin  
 Power Supply Cable Length: ..... 1.8m  
 Power ..... 1200W  
 Supply ..... 230V

## 4. INSTALLATION

### 4.1. WALL MOUNTING (IR12)

#### 4.1.1. MOUNTING LOCATION

- WARNING:** Locate the unit no closer than 0.3m to the ceiling, no less than 1.8m from the floor and no less than 1m from any side wall.
- WARNING:** Ensure the mounting surface is suitable and strong enough to securely and safely mount the unit (fixings not supplied).

4.1.2. Remove the four screws on the rear of the unit and use these to attach the unit mounting bracket to the unit with its orientation arranged in order to facilitate downward adjustment of unit when fitted to the wall mounting bracket. Ensure all fixings are firmly and securely attached.

4.1.3. Attach the wall mounting bracket to the mounting surface using suitable fixings (not supplied).

### 4.2. STAND MOUNTING (fig.1)


**NOTE:** Stand Mounting using IRCT Tripod (not supplied, can be bought in conjunction with IR12 in model number IR12CT).

4.2.1. Fit adaptor to the unit mounting bracket with the M8 hexagon head screw, washer and nut. Tighten screw to obtain grip without clamping the heater bracket totally. The heater angle can be adjusted by rotating about this fixing. Tighten securely after adjustment.

4.3. The tripod will be supplied assembled. Retract plunger at base of upright and pull or push central column tube through sleeve until the plunger "clicks" into the location hole. This will be the stands maximum height setting.

4.4. Slide the handle down the central column and fix with the thumb screw through the M8 hole.

4.5. Slide adaptor c/w heater into central column to full depth and clamp with thumb screw.



## 5. OPERATION

- WARNING! DO NOT** touch the top of the heater when in use as it becomes hot.
- WARNING!** Always allow elements to cool before moving the unit. Failure to do so will cause premature wear to the lamp and reduce its working life.
- WARNING!** This heater is not equipped with a device to control the room temperature. **DO NOT** use this heater in small rooms when occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

### 5.1. POWER ON/OFF

5.1.1. Connect to mains supply and use rocker switch set to either "I" for low power or "II" for high. Set rocker switch to "O" to turn off.

### 5.2. ANGULAR ADJUSTMENT (Wall mounted only)

5.2.1. To adjust the angle of the unit, loosen the hinge bolt, remove the angle locking screw and rotate the unit such that the alternative locking screw hole can be used. Tighten the hinge bolt to firmly and securely clamp the unit at the new angle.

## 6. MAINTENANCE

- × **WARNING!** Before attempting any maintenance, ensure the unit is unplugged from the mains power supply, and it is cool.
- × **DO NOT** touch the element glass, even when cold.
- × **DO NOT** use the heater without the grills fitted.

## 7. CLEANING

- 7.1. To clean the reflector, remove the front grill by unscrewing the retaining screws and wipe the reflector with a clean dry cloth. **DO NOT** use abrasives or solvents. The surface of the reflector is very soft and scratches may cause it to overheat. Replace the grille.
- 7.2. **FIT NEW ELEMENT**
- 7.2.1. To change the element remove the front grille by unscrewing the retaining screws.
- 7.2.2. Ease the sprung sockets on the ends of the element back and pull the element forward so that it clears the socket, remove element.
- ☐ **WARNING!** Never touch element glass directly with fingers, only touch the ceramic ends or use a soft cloth, to prevent damage.
- 7.2.3. Carefully insert the replacement lamp into the two push in side fittings with gentle pressure.
- 7.2.4. Check the element is properly located, then replace front grill.



### WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



### ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.



REGISTER YOUR PURCHASE HERE

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk



## Information requirements for electric local space heaters

Model identifier(s): IR12					
Item	Symbol	Value	Unit	Item	Unit
<b>Heat output</b>				<b>Type of heat input, for electric storage local space heaters only (select one)</b>	
Nominal heat output	$P_{nom}$	1.2	kW	Manual heat charge control, with integrated thermostat	Yes No <input checked="" type="checkbox"/>
Minimum heat output (indicative)* * Enter figure or NA	$P_{min}$	NA	kW	Manual heat charge control with room and/or outdoor temperature feedback	Yes No <input checked="" type="checkbox"/>
Maximum continuous heat output	$P_{max,c}$	NA	kW	Electronic heat charge control with room and/or outdoor temperature feedback	Yes No <input checked="" type="checkbox"/>
				Fan assisted heat output	Yes No <input checked="" type="checkbox"/>
<b>Auxiliary electricity consumption</b>				<b>Type of heat output/room temperature control (select one)</b>	
At nominal heat output	$eI_{max}$	1.1	kW	Single stage heat output and no room temperature control	Yes No <input checked="" type="checkbox"/>
At minimum heat output	$eI_{min}$	NA	kW	Two or more manual stages, no room temperature control	Yes <input checked="" type="checkbox"/> No
In standby mode	$eI_{SB}$	0	kW	With mechanic thermostat room temperature control	Yes No <input checked="" type="checkbox"/>
				With electronic room temperature control	Yes No <input checked="" type="checkbox"/>
				Electronic room temperature control plus day timer	Yes No <input checked="" type="checkbox"/>
				Electronic room temperature control plus week timer	Yes No <input checked="" type="checkbox"/>
				<b>Other control options (multiple selections possible)</b>	
				Room temperature control, with presence detection	Yes No <input checked="" type="checkbox"/>
				Room temperature control, with open window detection	Yes No <input checked="" type="checkbox"/>
				With distance control option	Yes No <input checked="" type="checkbox"/>
				With adaptive start control	Yes No <input checked="" type="checkbox"/>
				With working time limitation	Yes No <input checked="" type="checkbox"/>
				With black bulb sensor	Yes No <input checked="" type="checkbox"/>
Contact details: Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR. <a href="http://www.sealey.co.uk">www.sealey.co.uk</a>					
v1					ERP Table 2