

# SEALEY

## 2 TONNE/4 TONNE TELESCOPIC BOTTLE JACKS

MODEL NO'S: SJT2, SJT4

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear safety footwear



Beware crushing hands



Wear eye protection



Wear protective gloves

### 1. SAFETY

- WARNING! ALWAYS USE LOAD RATED STANDS TO SUPPORT LIFTED LOADS**
- ✓ Read, study and understand all warnings and operating instructions prior to use. The user shall work in accordance with this manual.
- ▲ **DANGER!** Use the jack for lifting and lowering only.
- ▲ **DANGER! DO NOT** place any part of the body beneath the lifted load unless the load is fully supported by rated axle stands.
- ▲ **DANGER! DO NOT** place any part of the body beneath the load during lifting or lowering.
- \* **DO NOT** exceed the rated capacity of the jack, load or maximum stroke.
- \* **DO NOT** adjust the overload valve, modify or use the jack for any purpose other than for which it is designed (lifting and lowering mechanical devices).
- \* **DO NOT** leave elevated loads unattended, unless safe from others in a garage or workshop.
- \* **DO NOT** modify the jack.
- ✓ The operator must watch the jack and the load during all movements.
- ✓ Ensure the jacking area is solid and level. Increase the jacking area with a solid flat plate (steel) if jacking on tarmac or grass.
- ✓ Keep others away from the work area.
- ✓ Lift only on areas of the vehicle specified by the vehicle manufacturer. Refer to manufacturer's instructions on proper lifting.
- ✓ Centre load on saddle prior to lifting.
- ✓ Some vehicles require an adapter to properly engage the frame for lifting.
- ✓ Use only attachments, restraints or adaptors supplied by the manufacturer.
- \* **DO NOT** move or dolly the vehicle whilst on the jack.
- ✓ Ensure the jacking area is clutter free and that there is adequate lighting.
- WARNING!** Remember, it is very dangerous to go under a vehicle supported by a jack even if additional supports are used.
- \* **DO NOT** go under a vehicle unless it is supported by adequately rated axle stands. NOTE: Seek advice before jacking caravans or trailers.
- WARNING!** The warnings, cautions and instructions in this manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.
- WARNING!** Failure to heed these warnings may result in personal injury and/or property damage.

### 2. INTRODUCTION

Fitted with overload valve. Dual-stage rams allow for longer travel. Lower retracted and higher extended heights. Base and reservoir machine welded for increased strength and eliminates leakage. Supplied with 3pc handle.

### 3. SPECIFICATION

Model No.	SJT2		SJT4	
	SJT2 Ram Height		SJT4 Ram Height	
Capacity	2tonne		4tonne	
Capacity Stage 1	4000kg	150-230mm	7500kg	170-245mm
Capacity Stage 2	2000kg	230-310mm	4000kg	245-330mm
Screw Extension	60mm		60mm	
Hydraulic Lift	160mm		170mm	
Maximum Height	370mm		390mm	
Minimum Height	150mm		160mm	



## 4. OPERATION

**Please remember a jack is a lifting and lowering device and is not designed to support a load. Never get underneath a vehicle supported only by a jack; your life is at risk. We stock a comprehensive range of axle stands, please see relevant catalogue section for full details.**

The jack is not limited to vehicle use only, with many applications in the engineering and construction industries.

- 4.1. The owner and/or operator is responsible for providing maintenance, maintaining decals or warning labels whilst in use, Maintaining the unit in good working order. If the owner and/or operator is not fluent in English, the product warnings and instructions shall be read in the operator's native language by the purchaser/owner or his deputy. Make sure operator understands its contents. Safety information shall be emphasised and understood prior to usage. The jack shall be inspected as per the instruction manual prior to use.
- 4.2. It is the owner's and/or the operator's responsibility to study all warnings, operating and maintenance instructions contained on the product label and instruction manual prior to operation of this unit. Owners and operators must retain this manual for future reference.

### ☐ **WARNING! Before use refer to section 1. SAFETY**

#### 4.3. **PURGING THE JACK**

- 4.3.1. Purge the hydraulic system in order to eliminate any air that may have accumulated in transit or whilst stored:
- 4.3.2. Turn release valve anticlockwise one full turn to open.
- 4.3.3. Pump handle eight full strokes.
- 4.3.4. Turn release valve clockwise to close valve.
- 4.3.5. Pump handle until the ram reaches maximum height and continue to pump several times to remove trapped air in the ram.
- 4.3.6. Carefully and slowly move top of oil filler plug aside to release trapped air.
- 4.3.7. Turn release valve anticlockwise one full turn and lower ram to its lowest position. Use force if necessary.
- 4.3.8. Turn release valve clockwise to closed position and check for proper pump action. It may be necessary to perform the above more than once to ensure the air is totally evacuated.

#### 4.4. **LIFTING THE LOAD**

- 4.4.1. Ensure the jack and vehicle are on a hard level surface.
- 4.4.2. Apply vehicle parking brake and chock the wheels.
- 4.4.3. Consult the vehicle owners manual to ascertain the location of jacking points and position jack beneath prescribed lifting point.
- 4.4.4. Turn the release valve clockwise to the closed position. **DO NOT** overtighten.
- 4.4.5. To raise the vehicle to the desired height, place the handle into the socket and pump up and down.
- 4.4.6. Place axle stands beneath the vehicle at locations recommended by the vehicle manufacturer. **DO NOT** get under the vehicle without it being supported by axle stands. Jacks are **NOT** designed to maintain heavy loads for long periods of time. **DO NOT** attempt to put axle stands simultaneously under both ends of the vehicle or under one side of the vehicle.
- 4.4.7. Turn release valve **SLOWLY** anticlockwise to lower the load onto jack stands.

#### 4.5. **LOWERING THE LOAD**

- 4.5.1. Turn the release valve clockwise to the closed position.
- 4.5.2. Pump the handle to lift the vehicle off the axle stands.
- 4.5.3. Remove the axle stands. **DO NOT** get under the vehicle or let anyone else under the vehicle whilst it is being lowered. Turn the release valve **SLOWLY** anticlockwise to lower the vehicle to the ground.

## 5. MAINTENANCE

**IMPORTANT! REPAIR AND MAINTENANCE OF THE JACK TO BE CARRIED OUT BY FULLY QUALIFIED PERSONNEL ONLY**

- ☐ **WARNING! DO NOT** use brake fluid, or any fluid other than Sealey hydraulic jack fluid. Use of non preferred jack oil may cause damage and invalidate the warranty.

#### 5.1. **INSPECTION**

- 5.1.1. The product must be maintained in accordance with these instructions. No alterations must be made to the product.
- 5.1.2. Before use a visual inspection should be made for abnormal conditions such as cracked welds, damage, bent, worn loose or missing parts or hydraulic leaks.
- 5.1.3. Inspection shall be performed in accordance with this manual.
- 5.1.4. The product shall be inspected immediately if the jack is believed to have been subject to abnormal load or shock.
- 5.1.5. It is recommended that inspection should be carried out by properly qualified personnel.

#### 5.2. **MAINTENANCE**

- 5.2.1. Monthly maintenance is recommended. Lubrication is critical to jacks as they support heavy loads. Any restriction due to dirt, rust, etc. can cause either slow movement or cause extremely rapid jerks, damaging the internal components. The following steps are designed to keep the jack well lubricated.
  - 5.2.1.1. Lubricate the ram, linkages, saddle and pump mechanism with light oil.
  - 5.2.1.2. Visually inspect for cracked welds, bent, loose or missing parts or hydraulic oil leaks.
  - 5.2.1.3. If jack is subjected to abnormal loads or shock, remove from service and have it examined by an authorised repair specialist.
  - 5.2.1.4. Check all surfaces and maintain all labels and warnings.
  - 5.2.1.5. Check and maintain the ram oil level.
  - 5.2.1.6. Check ram every 3 months for any sign of rust or corrosion. Clean as needed and wipe with an oily cloth. When not in use always leave with the ram fully retracted. This will help protect critical areas from excessive corrosion.

- ✖ **DO NOT** use brake or transmission fluids or regular motor oil as they will damage the seals. Always use Sealey hydraulic jack fluid. Use of non preferred jack oil may cause damage and invalidate the warranty.

#### 5.3. **CHECK OIL LEVEL**

- 5.3.1. Turn release valve counterclockwise to allow ram to fully retract. It may be necessary to apply force to the saddle to lower it.
- 5.3.2. With the jack in a level position, remove the oil filler plug. Stand the jack in a vertical position with the handle socket down. The oil should be level with the bottom of the filler hole. If not top it up. **DO NOT** overfill. Always fill with new, clean hydraulic oil.
- 5.3.3. Replace the oil filler plug.
- 5.3.4. Check jack operation.
- 5.3.5. Purge air from the system as required, refer to section 4.3.

## 6. TROUBLESHOOTING

Jack will not lift load	Jack will not lift load	Jack will not lower	Poor jack lifting	Will not lift to full extension	Causes and Solutions
X	X		X		Release valve is not completely closed. Turn handle clockwise.
X					Weight capacity exceeded.
X			X		Air is in the hydraulics. Purge air from the system.
X	X		X	X	Low oil level. Add oil as required.
		X			Oil reservoir is overfilled. Drain excessive oil. Lubricate moving parts.
		X			Jack is binding or foreign obstruction
X	X		X		Ram malfunctioning. Replace unit.



### ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk