



Item	Part No.	Description
1	RE97XM02.01	Hook
2	RE97XM02.02	Axle Pin
3	RE97XM02.03	Coupling Fork
4	RE97XM02.04	Collar
5	RE97XM02.05	Split Pin
6	RE97XM02.06	Nut
7	RE97XM02.07	Screw
8	RE97XM02.08	Ram
9	RE97XM02.09	Closing Ring
10	RE97XM02.10	Carrier Ring
11	RE97XM02.11	O-Ring, (Ex: 25.16 In: 20.58 Cs: 2.29)
12	RE97XM02.12	U-Type Packing
13	RE97XM02.13	Guiding Collar
14	RE97XM02.14	Nut
15	RE97XM02.15	Spring
16	RE97XM02.16	Shaft
17	RE97XM02.17	O-Ring, (Ex: 29.08 In: 18.42 Cs: 5.33)

Item	Part No.	Description
18	RE97XM02.18	Nut
19	RE97XM02.19	O-Ring, (Ex: 35.06 In: 29.82 Cs: 2.62)
20	RE97XM02.20	Cylinder
21	RE97XM02.21	Nut
22	RE97XM02.22	Screw Coupler
23	RE97XM02.23	Spindle Screw
24	RE97XM02.24	Spring
25	RE97XM02.25	Spindle
26	RE97XM02.26	Oil Ring
27	RE97XM02.27	Connection Nut
28	RE97XM02.28	Hose Coupler
29	RE97XM02.29	O-Ring, (Ex: 14.29 In: 9.66 Cs: 2.32)
30	RE97XM02.30	Dust Cap
--	RE97XM02.H-F	Hook Female for RE97XM02 2 Tonne (Not Shown)
--	RE97XM02.H-M	Hook Male for RE97XM02 2 Tonne (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.