



Item	Part No.	Description
1+21	CP20VPS-01+21	Controller (c/w Bracket)
2	CP20VPS-02A	Gearbox Assembly
2	CP20VPS-02B	Motor Assembly
3	CP20VPS-03	Spring
4	CP20VPS-04	Screw for Controller Bracket
5	CP20VPS-05	Screw for Casing
6	CP20VPS-06	Woolen Felt Ring
7	CP20VPS-07	Screw for Casing
8+19	CP20VPS-08+19	Casing Complete
9	CP20VPS-09	Magnet

Item	Part No.	Description
10	CP20VPS-10	External Circlip
11	CP20VPS-11	Pruning Blade
12	CP20VPS-12	Gear for Pruning Blade
13	CP20VPS-13	Washer
14	CP20VPS-14	Pruning Blade Pin
15	CP20VPS-15	Nut
16	CP20VPS-16	Screw for Gear
17	CP20VPS-17	Top Cover Protection
18	CP20VPS-18	Screw for Top Cover Protection
20	CP20VPS-20	Push Button

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.