



Item	Part No.	Description
1	DC2412.01	Output 12V DC
2	DC2412.02	USB Output 5V DC
3	DC2412.03	Front Panel
4	DC2412.04	Lower Panel
5	DC2412.05	PCB

Item	Part No.	Description
6	DC2412.06	Upper Panel
7	DC2412.07	Back Panel
8	PSI1000.04	Rd Head S/T Screw M3 x 6mm Black
9	DC2412.09	Bushing
10	DC2412.10	Cigarette Lighter Cord

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.