



Item	Part No.	Description	Qty
1	EH3001-V2-01	Cover, Grille	2
2	EH3001-V2-02	Grille	2
3	EH3001-V2-03	Outer Casing	1
4	EH3001-V2-04	Control Box	1
5	EH3001-V2-05	Selection Ring, Switch	2
6	EH3001-V2-29	Switch, On/Off Rotary - 16A/250V	1
7	EH3001-V2-07	Knob, Mode Selection Switch	1
8	EH3001-V2-08	Cable Grip	1
9	EH3001-V2-09	Tip-Over Switch 16A/250V	1
11	EH3001-V2-11	Thermostat 16A/250V	1
12	EH3001-V2-12	Heating Element 230V/300W	2
13	EH3001-V2-13	Thermal Cut-Out 16A/250V	1
14	EH3001-V2-14	Self-Resetting Thermostat	1
15	EH3001-V2-15	Capacitor 0.6µF/450V	1

Item	Part No.	Description	Qty
16	EH3001-V2-16	Fan	1
17	EH3001-V2-17	Motor (Internal 230V 50/60Hz)	1
18	EH3001-V2-18	Motor Support	1
19	EH3001-V2-19	Connect Plate	8
20	EH3001-V2-20	Inner Casing	1
21	EH3001-V2-21	End Cap	2
22	EH3001-V2-22	Rubber Foot	4
23	EH3001-V2-23	Adjusting Knob M8 x 35mm	2
24	EH3001-V2-24	Foot Stand, Right	1
25	EH3001-V2-25	Foot Stand, Left	1
26	EH3001-V2-26	Handle Grip	1

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.