



INSTRUCTIONS FOR TYRE STORAGE/TRANSPORT DOLLY

MODEL NO: **STR006**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual



Wear protective gloves

1. SAFETY

- WARNING!** Use tyre dolly on level and solid ground, preferably concrete. Ensure the floor over which the tyre dolly will be transported is swept clean.
- WARNING! DO NOT** use on tarmacadam or any other soft surface as the tyre dolly may sink or topple.
- WARNING!** If a loaded tyre dolly tips or leans **STOP WHAT YOU ARE DOING. MOVE QUICKLY TO A SAFE DISTANCE. DO NOT TRY TO HOLD OR STEADY THE TYRE DOLLY.**
- ✓ Use tyre dolly in a suitable work area, keep area clean and tidy and free from unrelated materials. Ensure there is adequate lighting.
- ✓ Before use, ensure that the size and weight of the wheels is known. **DO NOT** exceed the capacity of the tyre dolly.
- ✓ Maintain correct balance and footing when loading or moving the tyre dolly. Ensure the floor is not slippery and wear non-slip footwear.
- ✓ Observe correct manual handling techniques when loading wheels on to the tyre dolly. If in any doubt, obtain assistance.
- ✓ Ensure that tyres are loaded onto the tyre dolly such that all tyres are concentric to it and that the stack is stable.
- ✓ Apply castor wheel brake when the tyre dolly is stationary.
- WARNING! DO NOT** use tyre dolly if any parts are damaged or missing.
- ✗ **DO NOT** allow untrained persons to use the tyre dolly.
- ✗ **DO NOT** use the tyre dolly when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- ✗ **DO NOT** use tyre dolly for any purpose other than that for which it is designed.
- ✓ Before storing in safe area, ensure all parts are clean, free of grease and oil.
- WARNING:** The warnings, cautions and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.

2. INTRODUCTION

Tyre storage/transport dolly ideal for use with up to eight tyres. Four Ø75mm swivel TPR castors, one featuring a brake providing smooth and quiet manoeuvrability around the workplace. The dolly has a load capacity of 136kg.

3. SPECIFICATION

Model No: STR006
 Overall Size (W x D x H) 640 x 640 x 110mm
 Tyre Capacity: 8
 Maximum Weight Capacity 136kg

4. ASSEMBLY

- WARNING!** Ensure that you read, understand and apply Section 1 safety instructions.
- 4.1. Ensure that the swivel castors are securely assembled to the dolly using the supplied bolt set.
NOTE: One of the four supplied castors features a braking mechanism. Ensure that this is fitted.
- 4.2. If any parts are missing contact your Sealey stockist.



Parts support is available for this product. To obtain a parts listing and/or diagram, please log on to www.sealey.co.uk, email sales@sealey.co.uk or telephone 01284 757500



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk